



NURIT - RESTAURANT

Nurit 2085, 2085Plus, 2060, 2070, 2080

Customer Service: 800-201-0461
24-Hour Technical Support: 800-632-1888

CREDIT CARD SALE

TERMINAL DISPLAY	ACTION
CREDIT.....SALE ACCOUNT ->	Swipe the credit card with the magnetic strip facing down and away from the screen.
CREDIT.....SALE AMOUNT 0.00	Enter amount of sale (no need to press decimal). Once the desired amount appears on the screen, press ENTER .
DIALING 18**** PROCESSING... APPROVED	Terminal prints out an approval receipt.
TEARS SLIP -----> Press any key.....	Press any key to print out a customer copy (notice the customer's copy has the word COPY under the header).
CREDIT.....SALE ACCOUNT ->	Screen returns to original prompt.

MANUAL KEY IN - CREDIT CARD SALE (WITH AVS OPTION)

TERMINAL DISPLAY	ACTION
CREDIT.....SALE ACCOUNT ->	Manually key in the card number, press ENTER .
CREDIT.....SALE Exp. Date: ?	Manually key in the expiration date (mm,dd), press ENTER .
CREDIT.....SALE AMOUNT 0.00	Enter amount of sale (no need to press decimal). Once the desired amount appears on the screen, press ENTER .
Card Present? NO YES	Select your answer by pressing the black ATM-style keys under the selections.
<i>If the selection is NO:</i> Enter Zip Code: ■	Key in the credit card's billing zip code, press ENTER .
Street Address? ■	Key in the credit card's billing address. For example, if the billing address is 140 Main Street, you would enter 140 and then press ENTER .
DIALING 18**** PROCESSING... APPROVED	Terminal prints out an approval receipt.
TEARS SLIP -----> Press any key.....	Press any key to print out a customer copy (notice the customer's copy has the word COPY under the header).
CREDIT.....SALE ACCOUNT ->	Screen returns to original prompt

CREDIT CARD RETURN

TERMINAL DISPLAY	ACTION
CREDIT.....SALE ACCOUNT ?	Press the RETURN key.
CREDIT.....RETURN ACCOUNT ?	Swipe the credit card, or manually key in the account number and expiration date.
CREDIT.....RETURN AMOUNT ?	Enter amount of return (no need to press decimal) and press ENTER .
DIALING, PROCESSING, APPROVED	Terminal returns to original prompt, "CREDIT SALE.....ACCOUNT?".

VOID

TERMINAL DISPLAY	ACTION
CREDIT.....SALE ACCOUNT ?	Press the VOID key. The following transactions can be voided: credit card sale, forced sale, return.
CREDIT.....VOID/SALE ACCOUNT ?	Swipe the credit card, or manually key in the account number and expiration date.
CREDIT.....VOID/SALE AMOUNT ?	Enter amount of void (no need to press decimal) and press ENTER .
APPROVED OFF LINE	Terminal returns to original prompt, "CREDIT SALE.....ACCOUNT?".

FORCED CREDIT CARD SALE

TERMINAL DISPLAY	ACTION
CREDIT.....SALE ACCOUNT ?	Press the FORCED key.
CREDIT.....FORCED ACCOUNT ?	Swipe the credit card, or manually key in the account number and expiration date.
CREDIT.....FORCED AMOUNT ?	Enter amount of sale (no need to press decimal).
ENTER AUTH. NO	Enter authorization number obtained through voice auth.
APPROVED OFF LINE	Tear slip and have customer sign receipt.



NURIT - RESTAURANT

Nurit 2085, 2085Plus, 2060, 2070, 2080

BATCHING/SETTLEMENT

TERMINAL DISPLAY	ACTION
CREDIT.....SALE ACCOUNT ?	Press the BATCH key.
CHOOSE HOST: 1. ALL	Use the FORCED key to scroll through options. Make selection by pressing ENTER .
DIALING , 18005559999	Terminal will print detailed batch report.

COPY OF TRANSACTION RECEIPT

TERMINAL DISPLAY	ACTION
CREDIT.....SALE ACCOUNT ?	Press the ALPHA key.
RECEIPT COPY: 1: LAST RECEIPT (2. ANY RECEIPT)	Use the FORCED key to scroll through options. Make selection by pressing ENTER . If 1 is selected, terminal will print copy of last receipt.
<i>If 2 is selected, terminal will display:</i>	
CHOOSE EDC TYPE: 2. CREDIT (3. CHECK) <small>This will vary depending on EDC types available.</small>	Press ENTER to make selection.
TRANSACTION # ?	Enter transaction number and press ENTER .

ADDING TIPS

TERMINAL DISPLAY	ACTION
CREDIT.....SALE ACCOUNT ?	Press the EDIT key.
EDIT TIP BY: 1. TRANSACTION #	Scroll through the different options using the FORCED key.
Depending on option selected, terminal will prompt for different information	Enter the necessary information, and transaction will be displayed. If correct transaction, press ENTER .
BASE AMOUNT X.XX TIP AMOUNT 0.00	Press ENTER .
TIP AMOUNT 0.00	Enter tip amount and press ENTER .
TIP AMOUNT X.XX TOTAL X.XX	Terminal will display next transaction, or return to tip menu. Continue with same procedure.

IMPORTANT "VoIP" NOTICE

**ONLY IP CREDIT CARD TERMINALS ARE ABLE TO SUPPORT "VOICE OVER IP" (VoIP).
DIAL-UP TERMINALS WILL NOT WORK WITH VoIP SINCE THEY REQUIRE A LANDLINE.**

Changes made to your telephone system, such as converting to digital telephone service or Voice Over Internet Protocol (VoIP), can adversely affect the ability of your credit card terminal to function properly. Dial-up terminals do not work though VoIP. You must use a landline for dial-up terminals to function properly. If a dual communication terminal is present, a router must be used in conjunction with a DSL/cable modem to obtain a high speed connection.

If you plan on making any changes to the telephone system at the location where your terminal is used or if you have any questions in regards to your current terminal's capabilities, please contact technical support at 800-632-1888.